

Instruction Sheet

VIQUA PRO Series with Flow Meter Retrofit Kit

Overview

The PRO with flow meter technology has been designed and engineered by VIQUA to eliminate low UV nuisance alarms, which can occur regardless of water flow.

Benefits of the new flow meter include:

- Real-time dosing
- Fail-safe flow detection
- Triggers alarm only at genuine low UV issue

The PRO series with flow meter are the only NSF validated systems on the market that calculate real-time UV dosing.

Section 1 Safety Information

Please read this entire instruction sheet before operating this equipment. Pay attention to all danger, warning, and caution statements in this instruction sheet. Failure to do so could result in serious personal injury or damage to the equipment.

Make sure that the protection provided by this equipment is not impaired. Do not use or install this equipment in any manner other than that specified in the instruction sheet.

1.1 Safety Precautions

A DANGER



Failure to follow these instructions will result in serious injury or death.



Shock Hazard - Stored Energy



Disconnect power to system before performing any maintenance or repair.



There may be more than one source of power. Only connect to a GFCI.



Protective ground



DO NOT touch with wet hands.



Pressurized Device - Impalement Hazard



NEVER perform any physical inspection, repair or maintenance on UV chamber unless UV chamber has been isolated and depressurized.

NEVER service UV lamps, lamp sleeves or associated hardware until depressurization of UV chamber has been confirmed.



DO NOT store any combustible or flammable material close to the system.

AWARNING

Failure to follow these instructions could result in serious injury or death.

UV Light Hazard



- ALWAYS use UV protective gear, including gloves and UV safety glasses.
- NEVER look directly at illuminated UV lamp, even when using protective gear.




- NEVER illuminate UV lamp outside of the UV chamber.
- If accidental exposure occurs, immediately cool affected area and consult physician.



Contamination Hazard


If UV lamp breaks, avoid inhalation, ingestion, or exposure to eyes and skin. Wear appropriate clothing and personal protective equipment.



Failure to follow these instructions could result in minor or moderate injury.

Thermal Hazard







When there is no water flow, the water in the chamber will become hot. To prevent scalding, allow the system to cool for 10 minutes before draining the system.



Personal Injury Hazard

UV lamps and lamp sleeves are fragile. Do not strike, bend or apply pressure, or they will break.



DO NOT handle UV lamps or lamp sleeves with bare hands. Wear rubber or latex gloves to handle previously installed UV lamps and soiled lamp sleeves to protect against contaminants. Wear cotton gloves to handle new UV lamps and clean lamp sleeves.

System Protection



To protect the Controller, a UL 1449 certified (or equivalent) transient voltage surge suppressor is strongly recommended.

Avoid Injury

Read and understand this Instruction Sheet before operating and performing any maintenance on this equipment.

Warning: This product may contain chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.



Section 2 Installation

2.1 Flow Meter Installation

Procedure:




Figure 1 Old Installation




Figure 2 New Installation





425 Clair Rd. W, Guelph, Ontario, Canada N1L 1R1
t. (+1) 519.763.1032 • tf. (+1) 800.265.7246 (US and Canada only)
t. (+31) 73 747 0144 (Europe only) • f. (+1) 519.763.5069
e-mail: info@viqua.com
www.viqua.com